


物料名称：P系列说明书
物料编号：PP31-1
材质：100g双胶/CMYK
展开尺寸：360x210mm
成型尺寸：72x105mm


说明书正面(英文)




Professional Photographic Equipment

INSTRUCTIONS

P Series Monopod




GUANGDONG SIRUI OPTICAL CO., LTD.
Add: The Third Industrial District, Wuguishan Town, Zhongshan City,
Guangdong, China (Zip Code: 528458)
Tel: 86-760-88897373 Fax: 86-760-88207062
E-mail: info@sirui-photo.com Website: www.sirui.com




Max. Load

kg




Weight

kg




Max. Height

mm/inch




Max. Dia

mm/inch



Max. Dia

mm/inch



Section

mm/inch

4

28/1.1

19/0.7

1700/66.9

550/21.7

0.6/1.3

10/22.0

4

28/1.1

19/0.7

1700/66.9

550/21.7

0.6/1.3

10/22.0

4

32/1.3

22/0.9

1690/66.5

550/21.7

0.6/1.3

10/22.0

4

36/1.4

25/1.0


1700/66.9

560/22.0

0.6/1.3

15/31.1

1.Know your monopod



Upper and Lower Locking Screws ⑤
Mounting Screw
Platform
Belt hook ⑥
Wrist strap
Foam Grip
Leg Tube
Rubber Leg Locks
Retractable Stainless Steel Spike

2.Leg Extension and Closing




Figure 2

3.Retractable Stainless Steel Spike




Figure 3

4.Converting the Mounting Screw from 3/8" to 1/4"




Figure 1
Figure 3

1.Know your monopod

As shown in Figure 2, twist the rubber leg locks about 90 degrees in a clockwise direction ("a"), adjust the leg sections to the desired length and tighten the rubber leg locks by turning them in a counter-clockwise direction ("c").

2.Leg Extension and Closing

Twist the Rubber foot in a counter-clockwise direction ("a"), until the spike is fully extended; to retract the spike, turn in a clockwise direction ("c") until the spike is hidden.

3.Retractable Stainless Steel Spike

Most cameras and lens tripod sockets require a 1/4" screw. While many ball heads and medium format cameras require a 3/8" screw. As shown in Figure 1, loosen the Mounting Platform by turning it counter-clockwise ("a"), then twist the Mounting Screw out completely ("b"), flip the screw (Figure 2), twist it back into the monopod (turn clockwise) and hand tighten with the Mounting Platform ("c").


4.Converting the Mounting Screw from 3/8" to 1/4"

Using the allen key, gently twist the upper locking screw (on the mounting platform) into the base of the attached ball head for added stability. Twist the lower locking screw (on the leg of the monopod) to make the mounting plate more stable. Loosen if you wish to convert the mounting screw.


5.Locking Screws

Close the monopod when work is finished, you can easily carry your monopod by attaching the Belt Hook onto your belt.


Attention :




Do not exceed the recommended load limit of the head and/or monopod. (Please refer to product specifications.)




Please make sure that the locks are securely tightened when in use. For added safety, please put your wrist through the wrist strap when using the monopod.




This product should not be used in environments that exceed the following conditions (-40 ~ +100°C/-40 ~ +212°F). And, when used in damp, dirty or dusty environments, please clean and dry thoroughly after use, to assure proper functioning in the future. It is not recommended to expose this product to saltwater. If exposed, please clean with mild soap and warm water and towel dry.




Please keep from high temperatures and direct exposure to bright sunlight for extended periods of time.




To protect your camera gear, please remove it from the tripodball head when transporting from place to place.



Please use a soft towel with warm water and mild soap to clean the locking system and gliding parts when necessary. Towel dry before storing the monopod.



Under most situations, there is no need to lubricate any parts of this product. The addition of most lubricants will gum up the mechanisms and reduce their normal gliding characteristics. Please call or email us if you have any questions or special needs.



Please keep this product away from all electrical power sources.

CAUTION!

Do not place the monopod, with camera attached, over your shoulder or carry the monopod horizontally by the leg. Strong shaking may cause damage to the screw in the mounting plate and/or the camera. Please extend the legs from the biggest tube to smallest tube. Store the legs from the smallest tube to biggest tube. To avoid leg joint bending damage.

Dear SIRUI Customer,

Thank you for your purchase of SIRUI Professional Products! SIRUI warrants that your purchase is free from defects in materials and workmanship under normal use during the Limited Warranty Period. The Warranty begins on the original date of purchase on your sales receipt and is not transferable. If service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty Length
Tripods / Monopods / Accessories	6 years
Humidity Control Cabinet (Cabinet)	3 years
Humidity Control Cabinet (Electronics)	3 years

Model: _____ Date: _____

Store: _____ Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI 6 (six) Year Limited Warranty (3 Year Warranty for Electronic Parts). This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distributor's option, of defective parts, free of charge (except the cost of transportation to the distributor/service center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and Questions. SIRUI will not be responsible for expenses or inconveniences, or consequential damages to equipment, or by breach of any expressed or implied warranties.

Limitations:
Warranty is not transferable.
This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases:
1. If the equipment has been serviced by other than an authorized SIRUI Service Center.
2. Damage to the equipment is due to modification (including but not limited to, the removal of ballhead clamps), overloading, mishandling, abuse, accident, sand, corrosives, water damage or not following operating instructions.
3. No valid proof of purchase is provided.
4. Damage caused by acts of nature (including, but not limited to fires, floods or earthquakes).

Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.

Warranty Address and Contact Information:
(Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.)

1. Guangdong SIRUI Optical Co., Ltd.
The Third Industrial District, Wuguishan Town, Zhongshan City, Guangdong, China
Tel: 0086-760-88897373 Fax: 0086-760-88207062
Http://www.sirui.com E-mail: info@sirui-photo.com
Service Hotline: 0086-400 830 2299


2. SIRUI U.S.A. LLC
Add: 29 Commerce Court Verona, NJ 07044
www.siruiusa.com
Service: Toll Free 866-373-0829 E-mail: info@sirui.com
FOR PRODUCTS PURCHASED IN THE USA PLEASE SEE:
For full details on USA Warranty Terms and Limitations:
https://www.siruiusa.com/warranty.html
To register products: https://www.siruiusa.com/product-registration.html

3. Focus Nordic AB
For technical support, service or repairs, please contact:
Sweden: info@focusnordic.se www.focusnordic.se
Norway: info@focusnordic.no www.focusnordic.no
Denmark: info@focusnordic.dk www.focusnordic.dk
Finland: info@focusnordic.fi www.focusnordic.fi
Iceland: info@focusnordic.is www.focusnordic.is
Latvia: info@focusnordic.lv www.focusnordic.lv
Estonia: info@focusnordic.ee www.focusnordic.ee
Lithuania: info@focusnordic.pl www.focusnordic.lt
Poland: info@focusnordic.pl www.focusnordic.pl

4. TSE Imaging BV
Add: Argonweg 135 1362AD Almere, The Netherlands
Telephone: +31 (0)36 8450348 E-mail: service@tse-imaging.nl
(Exclusive Distributor for Netherlands, Belgium, Luxembourg)
www.sirui-photo.nl

5. 대원테크놀로지
한국 총판, 기술지원 및 보충 서비스 제공.
서울특별시 중구 남대문로 10, 1층
Tel: 02-752-3304 Fax: 02-774-9863
www.sirui.co.kr loweprokr@gmail.com


说明书背面(中文)




影像随心 思锐随行

使用说明

P系列独脚架




广东思锐光学股份有限公司
地址: 广东省中山市五桂山第三工业区 邮编: 528458
电话: 0760-88897373 传真: 0760-88207062 服务热线: 400 830 2299
邮箱: info@sirui-photo.com 网址: www.sirui.com




最大承重

kg




自重重量

kg




最大高度

mm




最大口径

mm



最大口径

mm



节数

mm

4

28

19

1700

550

0.6

10

4

28

19

1700

550

0.6

10

4

32

22

1690

550

0.6

10

4

36

25


1700

560

0.6

15

1.认识独脚架



紧固螺丝5
转接螺丝
转接平台
腰带挂扣6
挂绳
护手套
脚管
锁紧旋钮
可伸缩脚钉

2.伸延脚管




Figure 2

3.可伸缩脚钉




Figure 3

4.可倒转安装3/8"或1/4"固定螺丝




Figure 1
Figure 3

1.认识独脚架

按图示方向a, 同时或分别将锁紧旋钮转动1/4~1/2圈, 然后将脚管向下拉出(如图示方向b)至您所需要的长度, 再按图示方向c, 分别转动各个锁紧旋钮锁紧相应的脚管。

2.伸延脚管

切勿将产品长时间放在太阳下曝晒及避免高温环境, 例如长时间放在车内或玻璃后。

3.可伸缩脚钉

在公众地方使用时, 如在没有人照料下, 切勿留下设备而引致其他公众不便。

4.可倒转安装3/8"或1/4"固定螺丝

建议在运输过程中, 将设备(例如相机)从脚架上移除。


5.紧固螺丝

使用温和清洁剂及柔软毛巾清洁, 将尘埃及沙粒从所有锁制及活动部件清除。


6.腰带挂扣

除非有需要, 此设备无需定期加添润滑油, 如确实需要时, 请使用标准润滑油或油嘴。


注意事项:




不要超过最大的制定负重(请参考个别产品说明)。




当使用产品时, 把手腕套入手腕。




切勿在温度低于零下40摄氏度及高于100摄氏度使用。当在潮湿/沙地/布满尘埃的环境下使用后, 谨记将产品弄干及清洁, 不建议在海水中使用。




切勿将产品长时间放在太阳下曝晒及避免高温环境, 例如长时间放在车内或玻璃后。




在公众地方使用时, 如在没有人照料下, 切勿留下设备而引致其他公众不便。




建议在运输过程中, 将设备(例如相机)从脚架上移除。



使用温和清洁剂及柔软毛巾清洁, 将尘埃及沙粒从所有锁制及活动部件清除。



除非有需要, 此设备无需定期加添润滑油, 如确实需要时, 请使用标准润滑油或油嘴。



为自身安全着想, 切勿将产品接触任何电源。

温馨提醒

请勿将未收缩的独脚架直接夹入衣物或口袋一起放入洗衣机。清洗独脚架时, 请从最大管径的脚管到最小管径的脚管由外向内清洗。拆卸脚管时, 请从最小管径的脚管到最大管径的脚管由内向外清洗。

思锐公司保留产品升级和由于产品升级而变更各参数的权利, 请以实物为准, 恕不另行通知。
印刷品上如有印刷错误或因图方便的情况造成不便, 敬请包涵。

保修卡

尊敬的顾客:

感谢您购买思锐的产品! 在正常使用过程中, 如果因器材本身的材料工艺等出现质量问题, 思锐将为您提供免费的维修服务。在需要维修服务时, 请提供本保修卡和购买凭证(收据或发票, 须有商家盖章)。

思锐公司售后服务热线: 400 830 2299

产品名称	保修期限
脚架	6 年
云台	
防潮柜本体	3 年
电子部分	

产品型号: _____ 购买日期: _____

商店名称: _____ 商店电话: _____

商店地址: _____

商店盖章: _____

顾客须知:
(1) 思锐产品, 享受4年免费保修(电子部分为3年), 保修时间从购买之日起算。
(2) 所有保修产品, 必须是在思锐正式授权的经销商或电子商务处购买。
(3) 贵重物品及贵重配件, 请先拨打思锐服务热线, 待确认故障后, 思锐公司未和未收费, 一般故障保修(如)7个工作日内完成维修和更换。
(4) 向商家购买的故障, 请先确定发生问题的部件, 把故障件寄下寄回至思锐工厂维修即可。具体可参阅使用说明与或致电服务热线。
(5) 以下情况不在保修范围:
① 超过保修期限的;
② 在非思锐正式授权的经销商处购买的;
③ 在未思锐授权的代理商或维修中心维修过的;
④ 由于不正当使用、意外事件、自然灾害导致的故障或损坏。
※ 本保修卡只限在中国大陆使用

维修登记表A

用户姓名	用户电话
用户地址	邮 编
故障维修描述	维修人员签名
维修时间	

维修登记表B

用户姓名	用户电话
用户地址	邮 编
故障维修描述	维修人员签名
维修时间	

说明书折叠方法:

包装工程师: 彭少章

审核:

翻译:

批准: