


物料名称：TY-350说明书
物料编号：YZ76-1
材质：100g双胶/CMYK
展开尺寸：360x210mm
成型尺寸：72x105mm

说明书正面 (英文)




Professional Photographic Equipment

INSTRUCTIONS


TY-350

Telephoto Lens Support Plate



GUANGDONG SIRUI OPTICAL CO.,LTD.
Add: The Third Industrial District, Wuguishan Town, Zhongshan City, Guangdong, China (Zip Code: 528458)
Tel: 86-760-88897373 Fax: 86-760-88207062
E-mail: info@sirui-photo.com Website: www.sirui.com

1. Know your TY-350



TY-350 QR Telephoto Lens Support Plate

1/4" screw
3/8" screw
1/4" screw
3/8" screw

Non-slip rubber pad

1/4" screw

Camera QR Plate

Quick Release Clamp

Quick Release Clamp Locking Knob


Horizontal Adjustment Clamp

Adjustment Clamp Locking Knob


Horizontal Adjustment Rail

Adjustment Rail Stop

2. Attaching the TY-350



3. TY-350 Operation



Connect to Lens foot

Connect to Camera body

Tighten

Loosen

Tighten

1. Know your TY-350

The TY-350 is specially designed for supporting large telephoto lenses. The TY-350 Telephoto Support Plate is designed to fit on the SIRUI K-30X/K-40X Ball head (or other ball heads with Arca compatible quick release plates).

2. Attaching the TY-350

- ① Attach the Camera QR Plate onto your camera; then attach the Horizontal Adjustment Rail into the Horizontal Adjustment Clamp.
- ② Slide the TY-350 onto the Sirui K-30X/K-40X Ball Head and tighten the Clamp Locking Knob.

3. TY-350 Operation

- ① Loosen the Adjustment Clamp Locking Knob and move the Telephoto Lens Support Plate to its lowest position.
- ② Attach the lens onto the camera and slide the camera (with attached Camera QR plate) into the Quick Release Clamp.
- ③ Move the Telephoto Lens Support Plate up, until the non-slip rubber pads touch the lens' foot. Twist the 1/4" or 3/8" screw into the bottom of the lens foot. Tighten the Adjustment Clamp Locking Knob.
- ④ If the 1/4" screw on Camera QR plate is not compatible with your camera, you can remove it and simply rest the camera body on the platform (the lens foot will secure the equipment!). Please hold the camera when moving the outfit. You can also use the Camera QR plate as a standard QR plate on Sirui tripod and monopod heads.

4. Cautions

- ① To prevent excessive wear to the camera's tripod socket, you should not frequently attach and remove the Quick Release Plate. It is quite common to leave the QR Plate permanently attached to the camera.
- ② Please hold your camera while attaching and removing it from the QR Clamp.

66L7L199

TY-350


420×90×145

mm

Specifications

Weight

g/oz



TY-350 Data Chart

WARRANTY CARD INFORMATION

Dear SIRUI Customer,

Thank you for your purchase of SIRUI Professional Products! SIRUI warrants that your purchase is free from defects in materials and workmanship under normal use during the Limited Warranty Period. The Warranty begins on the original date of purchase on your sales receipt and is not transferable. If service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty Length
TriPods / Monopods / Accessories	6 years
Humidity Control Cabinet (Cabinet)	3 years
Humidity Control Cabinet (Electronics)	3 years

Model: _____ Date: _____

Store: _____ Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI 6 (six) Year Limited Warranty (3 Year Warranty for Electronic Parts). This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distributors option, of defective parts, free of charge (except the cost of transportation to the distributor/service center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and Questions. SIRUI will not be responsible for expenses or inconveniences, or consequential damages to equipment, or by breach of any expressed or implied warranties.

Limitations:
Warranty is not transferable.
This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases:
1. If the equipment has been serviced by other than an authorized SIRUI Service Center.
2. Damage to the equipment is due to modification (including but not limited to the removal of ballhead clamps), overloading, mishandling, abuse, accident, sand, corrosives, water damage or not following operating instructions.
3. No valid proof of purchase is provided.
4. Damage caused by acts of nature (including, but not limited to fires, floods or earthquakes).

Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.

Warranty Address and Contact Information:
(Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.)

1. Guangdong SIRUI Optical Co., Ltd.
The Third Industrial District, Wuguishan Town, Zhongshan City, Guangdong, China
Tel: 0086-760-88897373 Fax: 0086-760-88207062
Http://www.sirui.com E-mail: info@sirui-photo.com
Service Hotline: 0086-400-830-2299


2. SIRUI USA, LLC
Add: 29 Commerce Court Verona, NJ 07044
www.siruiusa.com
Service: Toll Free 866-373-0829 E-mail: info@sirui.com
FOR PRODUCTS PURCHASED IN THE USA PLEASE SEE:
For full details on USA Warranty Terms and Limitations:
https://www.siruiusa.com/warranty.html
To register products: https://www.siruiusa.com/product-registration.html

3. Focus Nordic AB
For technical support, service or repairs, please contact:
Sweden: info@focusnordic.se www.focusnordic.se
Norway: info@focusnordic.no www.focusnordic.no
Denmark: info@focusnordic.dk www.focusnordic.dk
Finland: info@focusnordic.fi www.focusnordic.fi
Iceland: info@focusnordic.is www.focusnordic.is
Latvia: info@focusnordic.lv www.focusnordic.lv
Estonia: info@focusnordic.ee www.focusnordic.ee
Lithuania: info@focusnordic.lt www.focusnordic.lt
Poland: info@focusnordic.pl www.focusnordic.pl

4. TSE Imaging BV
Add: Argonweg 135, 1362AD Almere, The Netherlands
Telephone: +31 (0)36 8450348 E-mail: service@tse-imaging.nl
(Exclusive Distributor for Netherlands, Belgium, Luxemburg)
www.sirui-photo.nl

5. 대광엔터테인먼트
한국 총판, 기술지원 및 보증서비스 제공.
서울특별시 중구 남대문로 10, 1층
Tel: 02-752-3304 Fax: 02-774-9903
www.sirui.co.kr loweprokr@gmail.com


说明书背面 (中文)



影像随心 思锐随行

使用说明


TY-350长镜头支撑系统



广东思锐光学股份有限公司

地址: 广东省中山市五桂山第三工业区 邮编: 528458
电话: 0760-88897373 传真: 0760-88207062 服务热线: 400 830 2299
邮箱: info@sirui-photo.com 网址: www.sirui.com

1.认识TY-350



TY-350快装板

防滑垫板

1/4"螺丝

3/8"螺丝

1/4"螺丝

3/8"螺丝

水平夹座快装板

水平夹座

水平夹座锁紧旋钮


竖向夹座

竖向夹座锁紧旋钮


竖向滑动快装板

止位挡板

2.安装TY-350



3. TY-350的基本操作



固定镜头脚

承托相机

紧

松

紧

松

1. 认识TY-350

TY-350长镜头支撑系统专为支撑摄影用长镜头而设，建议配合思锐K-30X/K-40X云台使用。

2. 安装TY-350

- ① 从包装中取出配件，将水平夹座快装板安装于水平夹座上，然后将竖向滑动快装板安装到竖向夹座上。
- ② 将准备好的TY-350安装到K-30X/K-40X云台上，锁紧云台夹座旋钮。

3. TY-350的基本操作

- ① 先将相机和长焦镜头安装在一起，再把水平夹座快装板安装到相机的底部。
- ② 将准备好的长焦镜头座放置在TY-350的防滑垫板上，目测相机底部的水平夹座快装板处于水平夹座的上方，利用TY-350快装板上1/4"和3/8"螺丝对镜头座进行连接固定。
- ③ 滑动竖向滑动快装板，让水平夹座快装板与水平夹座配合，然后锁紧。如快装板与夹座没对齐，可以适当松开长焦镜头座螺丝，调整镜头座在TY-350快装板上的位置，直到两处都能配合，这时可以旋紧螺丝以及夹座锁紧旋钮，锁紧设备。
- ④ 如水平夹座快装板上的1/4"螺丝与相机底部螺孔不匹配，可以将1/4"螺丝拧下，水平夹座快装板可以直接作为支撑相机之用。

4. 注意事项

- ① 建议不要经常从设备上拆装快装板，以避免损坏设备的安装螺丝孔。
- ② 在安装摄影设备时，请用扶稳设备，以防意外跌落。

01S

5145

TY-350


420×90×145

mm

规格

重量

g/oz



TY-350 Data Chart

保修卡

尊敬的顾客：

感谢您购买思锐的产品！在正常使用过程中，如果因器材本身的材料及工艺出现质量问题，思锐将会提供免费的保修服务。在需要保修服务时，请提供本保修卡和购买凭证（收据或发票，须有商家盖章），思锐公司将售后服务热线：400 830 2299

产品名称	保修期限
脚架	6 年
云台	
防潮柜本体	
电子部分	3 年

产品型号：_____ 购买日期：_____

商店名称：_____ 商店电话：_____

商店地址：_____

商店盖章：_____

顾客须知：

- ① 思锐产品，享受3年免费保修（电子部分为3年），保修时间从购买之日起。
- ② 所保修产品，必须是在正规授权的经销商或电子产品售后服务商。
- ③ 需寄回思锐工厂维修的，请先拨打思锐服务电话，待确认故障后，思锐公司将承担运费。一般性故障可在7个工作日内完成维修并寄回。
- ④ 防潮箱的保修，请先确定发生问题的部件，把该部件卸下并送到思锐工厂维修即可，保修金将按照使用说明书和购买凭证服务。
- ⑤ 以下情况不在保修范围内：
① 超过保修期限的；
② 在非正规授权经销商处购机的；
③ 在未报思锐售后中心或未经思锐中心检测过的；
④ 由于不正当操作、意外事件、自然灾害导致的故障或损坏。

※ 本保修卡只限在中国大陆使用


维修登记表A

用户姓名	用户电话	用户地址	邮 编
故障维修描述			
维修人员签名	维修时间		

维修登记表B


用户姓名	用户电话	用户地址	邮 编
故障维修描述			
维修人员签名	维修时间		

说明书折叠方法:




宽度2MM为一折,依次循环,直到折完为止,共5折

成品形状



成品尺寸



72 mm

105 mm

包装工程师: 彭少章

审核:

翻译:

批准: