


物料名称：BCT系列3节管说明书
物料编号：BCT15-1
材质：100g双胶/CMYK
展开尺寸：360x210mm
成型尺寸：72x105mm


说明书正面(英文)



Professional Photographic Equipment


INSTRUCTIONS

BCT Series Professional Video Tripod with 3 Sections



GUANGDONG SIRUI OPTICAL CO., LTD.
Add: The Third Industrial District, Wuguishan Town, Zhongshan City, Guangdong, China (Zip Code: 528458)
Tel: 86-760-88897373 Fax: 86-760-88207082
E-mail: info@sirui-photo.com Website: www.sirui.com

1. Know your tripod



2. Setting up the tripod on a flat, smooth surface

Fully loosen Leg Locking Knob A on all 3 legs, lift up from the Video Head Mounting Platform and re-tighten the locking knobs after the legs have fully extended. Spread the legs apart, until the Ground Spreader is flat on the ground. If additional height is needed, fully loosen Leg Locking Knob B on all 3 legs and follow the same procedure. Loosen Locking Knob C to extend the ground spreader to the desired position and re-tighten Locking Knob C (see fig. 2).

3. Retracting the tripod

Loosen the 3 Locking Knobs C, retract the Ground Spreader and re-tighten the Locking Knobs. Fully loosen the 3 Leg Locking Knobs A and B (see fig. 3-1), push down from the top of the tripod to collapse the legs, then re-tighten each locking knob. Pull up the Lift Ring in the middle of the Ground Spreader (see fig. 3-2), while holding the tripod and the three legs will move together (see fig. 3-3). Pull out the Leg Latch Hook and attach it onto the Latching Post on the adjacent leg to keep the tripod legs closed (see fig. 3-4).

4. Setting up the tripod on uneven ground

① Open the tripod (see fig. 4-1) and remove the Ground Spreader by pulling the Leg Buckle up and away from the leg (see fig. 4-2).

② Loosen the Center Spreader Locking Knob by turning counter-clockwise. The three arms attached to the center spreader can be moved up to 90° (see fig. 5-1); loosen the Center Spreader Extension Lock and the center arms can be extended (see fig. 5-2, 5-3).

③ Place the end of the Center Spreader next to the Center Spreader Connector, push the button on the Center Spreader Hook, position the hook onto the Center Spreader Connector and release. Tighten the Center Spreader Extension Lock (see fig. 6-2).

④ If you do not want to use the spikes, place the foot between the two spikes on the bottom of the leg. Pull the Buckle up and towards the leg and hook it onto the groove at the end of the leg (see fig. 6-3). You can adjust the legs to the desired angle by loosening the Center Spreader Connector and extending the arms as needed. Make sure that the longer section of the foot is facing away from the tripod.

Attention

Do not exceed the recommended load limit of the tripod head and/or tripod. (Please refer to product specifications.)

Please make sure that the locks are securely tightened when in use.

This product should not be used in environments that exceed the following conditions (40 ~ 100°C/40 ~ 212°F). And, when used in damp, dirty or dusty environments, please clean and dry thoroughly after use, to assure proper functioning in the future. It is not recommended to expose this product to saltwater. If exposed, please clean with mild soap and warm water and towel dry.

Please keep from high temperatures and direct exposure to bright sunlight for extended periods of time.

Please do not leave the equipment alone in a public place, which can be an inconvenience or hazard to others.

To protect your camera and video gear, please remove it from the tripod/video head when transporting from place to place.

Please use a soft towel with warm water and mild soap to clean the locking system and gliding parts when necessary. Towel dry before storing the tripod.

Under most situations, there is no need to lubricate any parts of this product. The addition of most lubricants will gum up the mechanisms and reduce their normal gliding characteristics. Please call or email us if you have any questions or special needs.

Please keep this product away from all electrical power sources.

Note: A separate video head with a 75mm (BCT2032203) or 100mm (BCT-3003203) ball and leveling base is required to attach your video camera to the tripod.

Specifications are subject to change without notice.

WARRANTY CARD INFORMATION

Dear SIRUI Customer,
Thank you for your purchase of SIRUI Professional Products!
SIRUI warrants that your purchase is free from defects in materials and workmanship under normal use during the Limited Warranty Period. The Warranty begins on the original date of purchase on your sales receipt and is not transferable. If service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty Length
Tripods / Monopods / Accessories	6 years
Humidity Control Cabinet (Cabinet)	3 years
Humidity Control Cabinet (Electronics)	3 years

Model: _____ Date: _____
Store: _____ Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI 6 (six) Year Limited Warranty (3 Year Warranty for Electronic Parts). This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distributors option, of defective parts, free of charge (except the cost of transportation to the distributor/service center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and Questions. SIRUI will not be responsible for expenses or inconveniences, or consequential damages to equipment, or by breach of any expressed or implied warranties.

Limitations:
Warranty is not transferable.
This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases:
1. If the equipment has been altered by other than an authorized SIRUI Service Center.
2. Damage to the equipment is due to modification (including but not limited to, the removal of built-in features), overloading, mishandling, abuse, accident, sand, corrosives, water damage or not following operating instructions.
3. No valid proof of purchase is provided.
4. Damage caused by acts of nature (including, but not limited to fires, floods or earthquakes).

Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.

Warranty Address and Contact Information:
(Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.)

1. Guangdong SIRUI Optical Co., Ltd.
The Third Industrial District, Wuguishan Town, Zhongshan City, Guangdong, China
Tel: 0086-760-88897373 Fax: 0086-760-88207082
Http://www.sirui.com E-mail: info@sirui-photo.com
Service Hotline: 0086-400 830 2299

2. SIRUI USA, LLC
Add: 29 Commerce Court Verona, NJ 07044
www.siruiusa.com
Service: Toll Free 800-373-0829 E-mail: info@sirui.com
FOR PRODUCTS PURCHASED IN THE USA PLEASE SEE: For full details on USA Warranty Terms and Limitations: https://www.siruiusa.com/warranty.html
To register products: https://www.siruiusa.com/product-registration.html

3. Focus Nordic AB
For technical support, service or repairs, please contact:
Sweden: info@focusnordic.se www.focusnordic.se
Norway: info@focusnordic.no www.focusnordic.no
Denmark: info@focusnordic.dk www.focusnordic.dk
Finland: info@focusnordic.fi www.focusnordic.fi
Iceland: info@focusnordic.is www.focusnordic.is
Latvia: info@focusnordic.lv www.focusnordic.lv
Estonia: info@focusnordic.ee www.focusnordic.ee
Lithuania: info@focusnordic.lt www.focusnordic.lt
Poland: info@focusnordic.pl www.focusnordic.pl

4. TSE Imaging BV
Add: Argonweg 135, 1362AD Almere, The Netherlands
Telephone: +31 (0)36 8450348 E-mail: service@tse-imaging.nl
(Exclusive Distributor for Netherlands, Belgium, Luxembourg)
www.sirui-photo.nl

5. 대영엔지니어링
한국 총판: 기술지원: 박종서 대표
서울특별시 중구 남대문로 10, 1층
Tel: 02-752-3304 Fax: 02-774-9903
www.sirui.co.kr loweprokr@gmail.com

说明书背面(中文)



影像随心 思锐随行

使用说明

BCT系列双级专业摄像三脚架



广东思锐光学股份有限公司
地址: 广东省中山市五桂山三乡工业区 邮编: 528458
电话: 0760-88897373 传真: 0760-88207082 服务热线: 400 830 2299
邮箱: info@sirui-photo.com 网址: www.sirui.com

1. 认识三脚架



2. 在平整的地面打开脚架

先把脚管的三个锁紧旋钮A完全松开, 待脚管向下完全滑出后再锁紧旋钮; 然后把脚管的三个锁紧旋钮B完全松开, 待脚管向下完全滑出后再锁紧旋钮。放置地面, 把锁钩解开, 然后把把地拖通过三个锁紧旋钮C松开至合适的位置, 再锁紧旋钮, 调整放置地点完成操作 (如图2)。

3. 收起脚架

先松开三个锁紧旋钮C, 把地拖收紧后锁紧旋钮; 然后把三个锁紧旋钮A和锁紧旋钮B全部松开 (如图3-1), 收缩各脚管后固定各旋钮, 然后把地拖中间的提环 (如图3-2), 整理三支脚管的密合度, 最后将锁钩扣到定位柱上 (如图3-3、3-4), 完成操作。

4. 在复杂的地面打开脚架

①把三脚架按步骤打开 (如图4-1), 再把地拖从三脚架上通过松开拉环取下 (如图4-2)。

②在扭松中置旋钮后, 可以实现中置三支脚在90°范围内转动 (如图5-1); 再扭松中置夹套旋钮, 可以加长中置支脚的行程 (如图5-2、5-3)。

③用手按住中置挂钩上的按钮, 分别卡入脚架相对应的卡槽内, 然后松开手实现中置与脚架的连接 (如图6-2)。

④将马踏放在脚架脚尖处相对应的卡槽内, 提拉环实现与脚架的连接 (如图6-3), 将脚管调整至合适角度, 再将中置旋钮锁紧, 最终实现脚架在复杂地面的使用。

注意事项:

- 不要超过最大的制造负重 (请参考产品说明书)。
- 当使用产品时, 时常紧锁其安全装置。
- 切勿在温度低于零下40摄氏度及高于100摄氏度使用, 当在潮湿/沙地/布泥的环境下使用时, 请清洁产品并干透再使用, 不建议在海水中使用。
- 切勿将产品长时间放在太阳下曝晒及避免高温环境, 例如长时间放在车内或窗台上。
- 在公共场所使用时, 如在没有人照料下, 切勿留下设备所引起其他公众不便, 建议在运输过程中, 将设备 (例如摄影机) 从脚架上移除。
- 使用温和清洁剂及柔软布巾清洗, 将尘垢及沙粒从所有机械及活动部件清除。
- 避免虫害, 此设备无需定期添加润滑油, 如确实需要时, 请使用标准润滑油或油脂。
- 为自身安全着想, 切勿将产品接触任何电源。

温馨提醒

请勿将三脚架连同未拆卸的摄影机一起乱扔抛洒, 剧烈的晃动可能会对摄影机造成损伤。

如果脚架损坏, 请从最大管径的脚管到最小管径的脚管的顺序拆解, 收缩脚管时, 请从最小管径的脚管到最大管径的脚管的顺序收缩。

思锐公司保留产品升级和由于产品升级而变更各参数的权利, 请以实物为准, 恕不另行通知。印刷品上如有任何错误造成使用方向的错乱和造成不便, 敬请包涵。

说明书折叠方法:

