

图纸名称：思锐K-X系列说明书
物料编号：YK38-3
材 质：100g双铜纸
展开尺寸：504x210mm
成型尺寸：72x105mm

说明书正面：



Professional Photographic Equipment

INSTRUCTIONS





K-X Series Ball Head













Guangdong SIRUI Optical Co., Ltd.
Address: The Third Industrial District, Niguanlan Town, Zhongshan City, Guangdong, China
Tel: 0860-760-8897373 Fax: 0860-760-8207192 Service Hotline: 0860-400-820299
E-mail: info@sirui-photo.com Http://www.sirui.com P.C: 528458

Model	Weight (g)	Height (mm)	Depth (mm)	Width (mm)
K-40X	54/21	124/49	0.80/1.76	35/17.2
K-30X	44/17	109/43	0.55/1.21	30/16.1
K-20X	38/15	101/40	0.43/0.95	25/15.1
K-10X	33/13	96/38	0.39/0.86	20/14.1

K-X Series Ball Head Data Chart

WARRANTY CARD INFORMATION

Dear SIRUI Customer,
Thank you for your purchase of SIRUI Professional Product! SIRUI warrants that your purchase is free from defects in materials and workmanship for a limited period of time. The Warranty begins on the original date of purchase on your sales receipt and is not transferable. A service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty Length
TriPods / Monopods / Accessories	3 years
Humidity Control Cabinet (Electronic)	6 years

Model: _____ Date: _____
Store: _____ Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI (USA) Limited Warranty (3 Year Warranty for Electronic Parts): This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distributors option, of defective parts, free of charge (except the cost of transportation to the distributor/service center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and/or contact information for regional distributors, or for expenses of repaired or replaced equipment, or by breach of any expressed or implied warranties.

Limitations:
This warranty is not transferable.
The warranty covers all defects encountered in normal use of the equipment and does not extend to the following conditions:
1. If the equipment has been serviced by other than an authorized SIRUI Service Center.
2. If the equipment has been modified in any way (including but not limited to, the removal of ballhead clamps, overloading, mishandling, abuse, accident, sand, corrosive, water damage or not following operating instructions).
3. No valid proof of purchase is provided.
4. Damage caused by normal use (including, but not limited to fire, floods or earthquakes).
5. SIRUI WaterProof/OutProof models - Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.

Warranty Address and Contact Information:
(Please contact the seller or the local distributor where the product was purchased for warranty issues or questions before any product is sent.)

1. Guangdong SIRUI Optical Co., Ltd.
Address: The Third Industrial District, Niguanlan Town, Zhongshan City, Guangdong, China
Tel: 0860-760-8897373 Fax: 0860-760-8207192
E-mail: info@sirui-photo.com Service Hotline: 0860-400-820299

2. SIRUI USA, LLC
Address: 200 Commerce Court Verona, NJ 07044
www.sirui.com
Tel: 866-373-9829 Fax: 908-866-3739829
E-mail: info@sirui.com
FOR PRODUCTS PURCHASED IN THE USA PLEASE SEE: For full details on USA Warranty, please visit: www.sirui.com/warranty.html To register product: www.sirui.com/product-registration.html

3. Focus Nordic AB
For technical support, service or repairs, please contact:
Sweden: info@focusnordic.se www.focusnordic.se
Denmark: info@focusnordic.dk www.focusnordic.dk
Finland: info@focusnordic.fi www.focusnordic.fi
Poland: info@focusnordic.pl www.focusnordic.pl
Estonia: info@focusnordic.ee www.focusnordic.ee
Lithuania: info@focusnordic.lt www.focusnordic.lt
Poland: info@focusnordic.pl www.focusnordic.pl

4. SIRUI Europe GmbH (European Service Center)
Address: Argonne 135, 1363AD Alsdorf, The Netherlands
Telephone: +31 20 365450348 E-mail: service@sirui-magnum.nl
(Please contact the seller or your local distributor for warranty issues.)
www.sirui-photo.nl

5. TSE Imaging BV
Address: Argonne 135, 1363AD Alsdorf, The Netherlands
Telephone: +31 20 365450348 E-mail: service@tseimaging.nl
(Please contact the seller or your local distributor for warranty issues.)
www.sirui-photo.nl

6. 대성옵티컬즈
한국 총판: 서울특별시 강남구 테헤란로 10, 18
Tel: 02-752-3304 Fax: 02-774-8903
www.sirui.kr.kw koreaper@tseimaging.com

Announcements

- Do not exceed the recommended load limit of the ball head and/or tripod. (Please refer to product specifications.)
- Please make sure that the locks are securely tightened when in use.
- This product should not be used in environments that exceed the following conditions (40 ~ 100°C/40 ~ 212°F).
- When used in damp, dirty or dusty environments, please clean and dry thoroughly after use, to assure proper functioning in the future.
- Please keep from high temperatures and direct exposure to bright sunlight for extended periods of time.
- To protect your camera gas, please remove it from the tripod ball head when transporting from place to place.
- Prevent sand, grit and other foreign matter from getting into the interior of the Ball Head. If the Ball Head does not move smoothly, please use a clean, soft cloth to gently wipe the Ball mechanism.
- There is no need to lubricate any parts of this product. The addition of lubricants will gum up the mechanisms and reduce their normal gliding characteristics. The construction of Sirui professional Ball Heads is very precise, so extra maintenance is not needed.
- Please keep this product away from all electrical power sources.

Specifications are subject to change without notice.


说明书背面：



影像随心 思锐随行

使用说明





K-X系列球形云台






广东思锐光学股份有限公司
地址: 广东省中山市东升镇山涌工业区 邮编: 528458
电话: 0760-8897373 传真: 0760-8207192 服务热线: 400-830-2299
邮箱: info@sirui-photo.com




型号	重量 (g)	高度 (mm)	深度 (mm)	宽度 (mm)
K-40X	54	124	0.80	35
K-30X	44	109	0.55	30
K-20X	38	101	0.43	25
K-10X	33	96	0.39	20

K-X系列云台参数表




认识云台

2. 安装云台

① 如果您的三脚架是UNC1/4"连接螺丝，那么您还需要另外购买一颗UNC3/8"的连接螺丝。

② 如图2-1、图2-2所示，把云台底部的UNC3/8"螺丝对准三脚架上的UNC3/8"螺丝，然后顺时针转动云台底座至牢固锁紧为止。

3. 认识快装板夹座和快装板

4. 快装板的安装拆卸

① 固定相机
根据相机的底部特点，选用合适的快装板，建议不要经常从相机上拆装快装板，以避免损坏相机的安装螺丝孔。(注：若快装板长期安装在相机上时，用手拧紧后再用我方配套的六角扳手夹紧即可)

② 安装快装板
如图4-1所示，把快装板逆时针方向松开，然后把快装板从夹座的侧槽推入并朝顺时针旋紧快装板螺母。注：快装板长期安装在相机上时，先松开快装板螺母，然后顺时针旋紧快装板螺母，从上方取出。

③ 快装板保险装置介绍
如图4-2所示，快装板夹座对快装板具有保险限位作用，防止不小心松开快装板螺母导致快装板意外脱落，损坏相机。

④ 快装板的拆卸
如图4-3所示，快装板上具有防止快装板意外脱落的保险按钮，当需要拆卸快装板时，先松开快装板螺母，然后按下保险按钮即可方便的取出快装板。也可以松开快装板螺母到一定位置，快装板从上方取出。

⑤ 相机底座的使用
云台标配带扣螺丝只在中间槽位使用。当为了调节相机重心而使使用左边或右边槽位时，需选用配套的圆头1/4"螺丝，如快装板图3-2所示。

5. 出厂设置

6. 基本操作

① 按此说明书第5点的出厂设置步骤，将云台恢复到出厂设置状态。

② 在云台上装上您的相机，并用手指扶住相机。

③ 如图7-1所示，晃动相机，并同时调节云台旋钮，以使相机扶住相机的手后，相机能够在任意角度位置稳定停留。

④ 如图7-2所示，顺时针方向旋转微调旋钮至转动为止。

⑤ 在支撑球有合适阻尼的情况下晃动球体至您想要的拍摄角度，然后锁紧云台旋钮。

7. 高级操作

① 解除锁定
任何原因造成的支撑球锁死状态，都按以下方法解除，特别注意不能转错方向。
① 如条件许可，如图8-1所示，安装在脚架上，用适当力按所指方向（顺时针）转动主旋钮1/10 ~ 1/2圈，切勿大力转动主旋钮。
② 如图8-2所示，按所指方向（逆时针）旋转微调旋钮。
③ 最后按本说明书所述，恢复出厂设置。

8. 解除锁定

任何原因造成的支撑球锁死状态，都按以下方法解除，特别注意不能转错方向。
① 如条件许可，如图8-1所示，安装在脚架上，用适当力按所指方向（顺时针）转动主旋钮1/10 ~ 1/2圈，切勿大力转动主旋钮。
② 如图8-2所示，按所指方向（逆时针）旋转微调旋钮。
③ 最后按本说明书所述，恢复出厂设置。

9. 维护和保养

爱护您的云台，不要让沙子等异物进入云台内部。如果云台转动不灵活，请用干净的软布轻轻擦拭球体，切勿使用油脂等任何润滑剂。思锐专业云台结构精密，不需要任何额外的维护。

维修卡

尊敬的客户：
感谢您购买思锐的产品。在使用过程中，如果发现器材本身的材料及工艺出现问题，我们将为您提供免费的维修服务。在维修期间，请妥善保管器材，避免造成不必要的损失。维修期间，我们将免费提供器材，如有损坏，我们将照价赔偿。

产品名称	保修期限
脚架	6年
云台	3年
防潮柜本体	3年
电子部分	3年

产品名称：_____ 购买日期：_____

商店名称：_____ 商店电话：_____

商店地址：_____

商店邮编：_____

维修日期：_____

维修人员姓名：_____

维修时间：_____

维修记录表A

用户姓名	用户电话	用户地址	邮编

故障描述：_____

维修人员姓名：_____

维修时间：_____

维修记录表B


用户姓名	用户电话	用户地址	邮编

故障描述：_____

维修人员姓名：_____

维修时间：_____

折叠方法：



72 mm

105 mm

成型尺寸