


图纸名称：3T-15+B-00套装系列说明书  
物料编号：PT202-1  
材 质：100g双胶/CMYK四色印刷  
展开尺寸：576x210mm  
成型尺寸：72x105mm

3T-15说明书正面(英文版):




SIRUI WEBSITE

QUANGDONG SIRUI OPTICAL CO., LTD.  
Add: The Third Industrial District, Wugushan Town, Zhongshan City,  
Guangdong, China (Zip Code: 528481)  
Tel: 86-750-8887773 Fax: 86-750-8850782  
E-mail: info@sirui-photo.com Website: www.sirui.com

### Instructions

3T-15 + B-00 Series Tripod Kit



#### 1. Know the Product




Fig.1

#### 2. Know the Quick Release Plate and Quick Release Clamp

(1) Quick Release Plate




Fig.2-1

(2) Quick Release Clamp




Fig.2-2

#### 3. Install and Remove the Quick Release Plate




Fig.3-1 Fig.3-2 Fig.3-3 Fig.3-4

#### 4. Operation - 2 Angles Adjustment of Tripod




Fig.4-1 Fig.4-2 Fig.4-3

Turn the Mounting Platform Counter-clockwise to the "Click" to adjust the legs for high angle.

Turn the Mounting Platform Clockwise to the "click" to adjust the legs for low angle.

#### 4. Operation - Straps




Fig.4-4

Fig. b - Thread the Straps through the Buckles for tightening.

#### 4. Operation - Ball Head




Fig.4-5

1. Attach your camera to the Ball Head.  
2. Move the Ball Head to the desired place by adjusting the friction of the ball, then lock the Main Locking Knob.

#### 5. Ball Head can be used on other SIRUI Tripods




Fig.5-1 Fig.5-2

Remove the 1/4" to 3/8" screw adapter cap from the base of the Ball Head, the Ball Head can be attached to other SIRUI Tripods (Fig.5-1 and Fig.5-2).

#### Attention:

Do not exceed the recommended load limit of the head and/or tripod. (Please refer to product specifications.)

Please make sure that the locks are securely tightened when in use.

This product should not be used in environments that exceed the following conditions (40°~80°C/104°~176°F). And, when used in damp, dirty or dusty environments, please clean and dry thoroughly after use, to assure proper functioning in the future. It is not recommended to expose this product to saltwater. If exposed, please clean with mild soap and warm water and towel dry.

Please keep from high temperatures and direct exposure to bright sunlight for extended periods of time.

Please do not leave the equipment alone in a public place, which can be an inconvenience or a hazard to others.

To protect your camera gear, please remove it from the tripod/ball head when transporting from one place to another.

Please use a soft towel with warm water and mild soap to clean the locking system and gliding parts when necessary. Towel dry before storing the tripod.

Under most situations, there is no need to lubricate any parts of this product. The addition of most lubricants will gum up the mechanisms and reduce their normal gliding characteristics. Please call or email us if you have any questions or special needs.

Please keep this product away from all electrical power sources.

#### Warranty Card Information

Dear SIRUI Customer:  
Thank you for your purchase of SIRUI Professional Products!  
SIRUI warrants that your purchase is free from defects in materials and workmanship under normal use during the Limited Warranty Period. The Warranty begins on the original date of purchase on your sales receipt and is not transferable. If service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty / Accessories	Warranty Length
Tripods / Monopods / Accessories		6 years
Humidity Control Cabinet (Cabinet)		3 years

Model: \_\_\_\_\_ Date: \_\_\_\_\_  
Store: \_\_\_\_\_ Serial Number: \_\_\_\_\_

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI (six) Year Limited Warranty (3 Year Warranty for Electronic Parts)  
This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distribution option, of defective parts, free of charge (except the cost of transportation to the distributor/supplier's center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and Questions. SIRUI will not be responsible for expenses or inconvenience, or consequential damages to equipment, or by breach of any expressed or implied warranties.

Limitations:  
Warranty is not transferable.  
This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases:  
1. If the equipment has been serviced by other than an authorized SIRUI Service Center.  
2. Damage to the equipment is due to modification (including but not limited to, the removal of ballhead cameras), overloading, mishandling, abuse, accident, and/or corrosive, water damage or not following operating instructions.  
3. No valid proof of purchase is provided.  
4. Damage caused by acts of nature (including, but not limited to fires, floods or earthquakes).

Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.


Warranty Address and Contact Information:  
(Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.)

1. Guangdong SIRUI Optical Co., Ltd.  
The Third Industrial District, Wugushan Town, Zhongshan City, Guangdong, China.  
Tel: 86-750-8887773 Fax: 86-750-8850782  
E-mail: info@sirui-photo.com  
Service Hotline: 0086-830-830-2299  
Complaint Hotline: +86-181-6563-5388  
(Monday to Friday: 9:15am-12:15pm, 14:00pm-18:00pm)

2. SIRUI USA, LLC  
Add: 29 Commerce Court Verona, NJ 07044  
www.sirui.com  
Service: Toll Free 866-373-5829 E-mail: info@sirui.com  
FOR PRODUCTS PURCHASED IN THE USA PLEASE SEE:  
Tel: 866-8887773 Fax: 866-8850782  
E-mail: info@sirui-photo.com  
Service Hotline: 0086-830-830-2299  
Complaint Hotline: +86-181-6563-5388  
(Monday to Friday: 9:15am-12:15pm, 14:00pm-18:00pm)

3. European Service Center  
Add: SIRUI Optical GmbH • Ernst-Augustin-Str. 1a • 12489 Berlin • Germany  
Phone: +49 30 991 94 90-0 E-mail: info@srui-optical.eu

3T-15说明书背面(中文版):




SIRUI中文官网

广东思锐光学股份有限公司  
地址：广东省中山市五桂山街道三工业集聚区 邮编：528481  
电话：0750-8887773 传真：0750-8850782 服务热线：400-830-2299  
邮箱：info@sirui-photo.com 网址：www.sirui.com  
股票代码：1816583888  
（深圳证券交易所：15-1211-14-00-18-000）

### 使用说明

3T-15+B-00套装系列



#### 1. 认识产品




图1

#### 2. 认识快装板和快装板夹座

(1) 快装板




图2-1

(2) 快装板夹座




图2-2

#### 3. 快装板的安装拆卸




图3-1 图3-2 图3-3 图3-4

#### 4. 基本操作-1<支架的两种支撑角度>




图4-1 图4-2 图4-3

如图4-1所示  
按箭头方向打开支撑脚  
向左或向右转动转台能将支撑脚  
在两个档位之间进行变换

如图4-2所示  
往右方向转动转台得到高角度拍摄档

如图4-3所示  
往左方向转动转台得到低拍摄档

#### 4. 基本操作-2<固定带的使用方法>




图4-4

图a-将固定带穿进支撑脚上的孔。

图b-将固定带穿进转台支撑脚上的孔。

#### 4. 基本操作-3<云台基本操作>




图4-5

1. 在云台上装上您的相机，并用手持住相机。  
2. 在支撑球有合适阴影的情况下晃动球体至您想要的拍摄位置，然后锁紧主旋钮。

#### 5. 云台可接到其它脚架使用




图5-1 图5-2

可以拆下云台底部的1/4"与3/8"螺丝转接帽进行拆卸下来

安装到思锐其它脚架上使用

#### 注意事项:

不要超过最大的额定负重 (请参考个别产品说明);

当使用产品时, 时常紧锁其安全装置;

切勿在温度低于零下40摄氏度及高于80摄氏度使用, 当在潮湿、沙地、布满尘埃的环境下使用后, 请记得将产品弄干及清洁, 不建议在海水中使用;

切勿将产品长时间放在太阳下曝晒及避免高温环境  
例如长时间放在车内或玻璃后;

在公众地方使用时, 如在没有人照料下, 切勿留下设备而引致其他公众不便;

建议在运输过程中, 将设备 (例如相机) 从脚架上移除;

使用温和清洁剂及柔软毛巾清洁, 将尘埃及沙粒从所有锁制及活动部件清除;

除非有必要, 此设备无需定期添加润滑油, 如确实需要时, 请使用标准润滑油或油蜡;

为自身安全着想, 切勿将产品接触任何电源。

#### 保修卡

尊敬的顾客:

感谢您购买思锐的产品! 在正常使用过程中, 如因器材本身的材料及工艺出现质量问题, 思锐将会提供免费的保修服务。在需要保修服务时, 请提供本保修卡和购买凭证 (收据或发票, 须有商家盖章), 思锐公司售后服务热线: 400 830 2299

产品名称	保修期限
脚架	6年
云台	
防潮柜本体	
电子部分	3年


产品型号: \_\_\_\_\_ 购买日期: \_\_\_\_\_  
商店名称: \_\_\_\_\_ 商店电话: \_\_\_\_\_  
商店地址: \_\_\_\_\_  
商店盖章: \_\_\_\_\_

顾客须知:

- 思锐产品, 享受6年免费保修 (电子部分为3年), 保修时间从购买之日起算;
- 所保修产品, 必须是思锐正式授权的经销商或电子商务处购买;
- 需经同思锐工厂维修的, 请先拨打思锐服务电话, 待确认故障后, 思锐公司承担来回运费, 一般性故障可在7个工作日内完成维修并寄回;
- 防潮柜的保修: 请先确定发生问题的部件, 把该部件卸下单独邮寄回思锐工厂维修即可, 具体可参阅使用说明书或致电服务热线;
- 以下情况不在保修范围:
  - ① 超过保修期限的;
  - ② 在非思锐正式授权经销商处购买的;
  - ③ 在未报思锐授权的代理商或维修中心维修过的;
  - ④ 由于不当操作、意外失误、自然灾害导致的故障或损坏。
- 本保修卡只限在中国大陆使用


用户姓名	用户电话	用户地址	邮编	故障维修描述	维修人员签名	维修时间

说明书折叠方法:



成品形状

成品尺寸



成品尺寸